



ASPEROR CIRCULO COMPLETO ECO. S/TOR-DIF		
Ent. Pulg.	Modelo	CLAVE
M - 1/2"	T-13-E	HTACC000013001



ASPEROR CIRCULO COMPLETO ECO. C/TOR-DIF		
Ent. Pulg.	Modelo	CLAVE
M - 1/2"	T-13-E-TD	HTACC000013002



ASPEROR CIRCULO COMPLETO C/CHUMACERA		
Ent. Pulg.	Modelo	CLAVE
M - 1/2"	T-13-CH-TD	HTACC000013003



ASPEROR CIRCULO COMPLETO DOS BOQUILLAS		
Ent. Pulg.	Modelo	CLAVE
M - 1/2"	T-13-G2	HTACC001013001
M - 3/4"	T-20-G2	HTACC001019001



ASPEROR AJUSTABLE C/TORNILLO DIFUSOR		
Ent. Pulg.	Modelo	CLAVE
M - 1/2"	N13-VP	HTAAT001013001
M - 3/4"	20-VP	HTAAT001019001



ASPEROR CIRCULO COMPLETO DOS BOQUILLAS		
Ent. Pulg.	Modelo	CLAVE
H - 1"	T-27-G2	HTACC001025002



ASPEROR AJUSTABLE C/TORNILLO DIFUSOR		
Ent. Pulg.	Modelo	CLAVE
H - 1"	25-VP	HTAAT001025002



VALVULA DE ACOPLAMIENTO RAPIDO		
Ent. Pulg.	Modelo	CLAVE
3/4"	V-20	HTVAR001019001
1"	V-25	HTVAR001025001



ACOPLADOR P/VALVULA DE ACOPLAMIENTO RAPIDO		
Ent. Pulg.	Modelo	CLAVE
M 3/4"-H 1/2"	A-20	HTVAA001019001
M 1"-H 3/4"	A-25	HTVAA001025001



CODO GIRATORIO P/MANGUERA

Ent. Pulg. Modelo CLAVE

3/4" C-20 HTVAC001019001
1" C-25 HTVAC001025001



BASE ESTACA DURALUMINIO

Ent. Pulg. Modelo CLAVE

A 1/2"-E 3/4" BE-20-13 HTVAB001013019



ROCIADOR SUBTERRANEO P/PASTO

Circulo Modelo CLAVE

90° 13-Q HTROS001013090
180° 13-H HTROS001013180
360° 13-F HTROS001013360



ROCIADOR SURGENTE P/PASTO

Circulo Modelo CLAVE

90° 13-SUR-Q HTROS002013090
180° 13-SUR-H HTROS002013180
360° 13-SUR-F HTROS002013360



ROCIADOR DE ARBUSTO

Circulo Modelo CLAVE

90° 13-AR-Q HTROS003013090
180° 13-AR-H HTROS003013180
360° 13-AR-F HTROS003013360



BOQUILLA P/ROCIADOR CATARINA O FLOR

Accesorio Modelo CLAVE

Boquilla BO-F HTROJ000013360



ROCIADOR P/JARDIN P/CONECTOR MOV. P/MANGUERA

Circulo Modelo CLAVE

360° CATARINA HTROJ001013360



ROCIADOR P/JARDIN P/CONECTOR MOV. P/MANGUERA

Circulo Modelo CLAVE

360° FLOR HTROJ002013360